





## E TURN AND AND THE REAL PROPERTY OF THE PARTY OF THE PART

## PREVENTION AND TREATMENT

## Prevention

- \* Apply suitable finish
- \*Make sure surface is sanded smooth with no cracks or crevices
- Polish surface

## **Treatment**

- \* Remove all dust and dirt
- Apply one or two coats of insecticide
  - brush into cracks etc.
- Apply insecticide into adjoining timber.
- ❖ Inject into some of the flight holes









